

## TRANSDUCER PROTECTOR

### ◆ Male Luer Lock / Female Luer Lock



TP-NKK01TT1



TP-NKK01WT1



TP-NKK01RT1



TP-NKK01YT1



TP-NKK01BT1

### ◆ Luer Slip / Female Luer Lock



TP-NSK01TT1



TP-NSK01WT1



TP-NSK01RT1



TP-NSK01YT1



TP-NSK01BT1

### ◆ Tubing Port / Female Luer Lock



TP-NTK01TT1



TP-NTK01WT1



TP-NTK01RT1



TP-NTK01YT1



TP-NTK01BT1

### ◆ Male Luer Lock / Tubing Port



TP-NKT01TT1



TP-NKT01WT1



TP-NKT01RT1



TP-NKT01YT1



TP-NKT01BT1

### ◆ Luer Slip / Tubing Port



TP-NST01TT1



TP-NST01WT1



TP-NST01RT1



TP-NST01YT1



TP-NST01BT1

### ◆ Tubing Port / Tubing Port



TP-NTT01TT1



TP-NTT01WT1



TP-NTT01RT1



TP-NTT01YT1



TP-NTT01BT1