



STERIPLUS™ 40

INTEGRATED SYSTEM WITH PRELIMINARY SHREDDING AND STEAM STERILIZATION OF YOUR BIOHAZARDOUS WASTE

The **STERIPLUS™** systems from **Tesalys** are the ideal solution to inactivate your biohazardous waste safely on-site. Its integrated shredding system **TESASHRED™** not only reduces the volume and mass of waste, but also ensures waste is fully processed.

TESALYS

Main address
7, rue du Cassé
31240 Saint-Jean (Toulouse)
France

Tel. +33 5 62 10 18 91
info@tesalys.fr

www.tesalys.fr



STERIPLUS™ 40

integrated system with preliminary shredding and steam sterilization of your biohazardous waste



UTILITIES

WATER

REQUIREMENTS Softened or drinking quality water
CONSUMPTION Approx. 10 liters/cycle

ELECTRICITY

REQUIREMENTS 380-400 V III N, 50Hz/60Hz, 10 kW
CONSUMPTION 4 to 5 kWh/cycle

DRAIN

32 mm Ø internal (heat-resistant)(1.2")

STEAM/COMPRESSED AIR

Produced by the integrated steam generator and air compressor; no external connection required.

(1) 30-35min for test loads as per NF X30-503-1 standard.

(2) Cycle times may vary based on the type of materials, waste density, humidity, quantity of liquids, etc. For loads with high liquid content, cycle time can be longer. Up to 50min depending on the waste density.

(3) Based on an average cycle time of 45min. (40 min. of cycle + 5 min. unloading/loading time).

(4) Quantity of liquids allowed might vary depending on application (urine bags, blood bags, food testing bags, ...).

All the data given in this catalog are non-binding and given as a guide only. Treatment capacities and cycle times are given as mere examples and may vary depending on the type of waste, installation conditions, operator's availability and skills.

LOADING CHAMBER CAPACITY	40 L
LOADING CHAMBER USEFUL DIMENSIONS (W x D x H)	320 x 247 x 520 mm
LOADING CAPACITY (CONTAINERS)	1 x TESABOX 40 or 2 x TESABOX 20
TOTAL CYCLE TIME (NF X30-503-1 STANDARD) (1)	30 to 35 min
TOTAL CYCLE TIME IN WORKING CONDITIONS (2)	30 to 50 min
LOADING CAPACITY (KG/CYCLE)	Based on an average waste density of 0,08 to 0,12kg/L for Healthcare Waste 3,2 to 4,8 kg/cycle
	Based on an average waste density of 0,12 to 0,2kg/L for Lab/Humid/Liquid Waste 4,8 to 8 kg/cycle
	Based on an average waste density of 0,08 to 0,12kg/L for Healthcare Waste 4 to 6 kg/h
TREATMENT CAPACITY (KG /H) (3)	Based on an average waste density of 0,12 to 0,2kg/L for Lab/Humid/Liquid Waste 6 to 10 kg/h
MAX QUANTITY OF LIQUID RECOMMENDED PER CYCLE (4)	12 L
EXTERNAL DIMENSIONS (W x D x H)	1300 x 895 x 1450 mm
NET WEIGHT	580 kg
LOADING CHAMBER	Stainless steel with PTFE coating
TREATMENT CHAMBER	AISI 304L stainless steel
STEAM GENERATOR	AISI 304L stainless steel (chamber) & Highly corrosion-resistant Hastelloy®
WATER SOFTENER	Built-in
WATER BOOSTER PUMP AND AIR COMPRESSOR	Built-in
WASTE SHREDDER	Structure: AISI 304L stainless steel & Blades: High-strength steel
PIPING	Stainless steel/PTFE flexible hosing
CHASSIS	Painted steel
BODYWORK	Composite material/Painted steel
CYCLE TRACEABILITY Through printout	Built-in
USB PORT	Built-in

A complete range for biohazardous waste treatment



STERIPLUS™ 20
2/5 kg/h



STERIPLUS™ 40
4/10 kg/h



STERIPLUS™ 80
8/20 kg/h



TESABAG
Autoclavable
biohazardous waste bags



TESABOX
Cardboard containers
for biohazardous waste